

Manual ALL3505

Table of Contents

>>>>>> TBD <<<<<<<<

scope of supply

Please check the packaging and contents for damage:

Is there any indication on the packaging that something has been damaged during transport?

Are there signs of wear on the housing?

Under no circumstances must you put the device into operation if it is damaged. In case of doubt, please contact our technical customer service.

Packaging contents:

- ALLNET® ALL3505 IP Home Automation Central Unit
- 1x network cable
- 1x 230V connection cable
- 1x ALL3006 Temperature sensor
- user's manual

safety notices

It is imperative that you observe the following notes:

- Never open the device.
- Never perform an installation during a thunderstorm.
- Make sure that cables are laid in a tripping and non-slip manner.
- Do not expose the device to direct sunlight.
- Never place the device near heat sources.
- Never place the unit on surfaces that are sensitive to heat.
- Protect the device from moisture, dust, liquids and vapours.
- Do not use the device in damp rooms and never in potentially explosive atmospheres.
- Do not use any cleaning agents containing solvents, only a soft, dry antistatic cloth.
- Repairs may only be carried out by trained, authorised personnel.
- ALLNET® accepts no liability for improper use.

Installation and assembly site

General:


The ALL3505 IP Home Automation Central Unit may only be used in dry indoor areas. Ensure adequate ventilation. Installation must be carried out in such a way that the cables (network cables and connection cables as well as the connection cables of the consumers) are not under tension, otherwise they may come loose.

Translated with [www.DeepL.com/Translator](http://www.DeepL.com/Translator)

**Front-Ansicht:**



Rück-Ansicht:



delineation

## **The new central unit for your building control system**

The ALLNET ALL3505 IP Home Automation Central Unit automates all tasks in building control, such as recording and signalling environmental conditions such as temperature, humidity, pressure and much more, as well as triggering switching operations via contacts, relays and the like. This can be done manually, time-controlled or depending on the values entered.

Various scenarios such as lighting, blinds, ventilation and household appliances can be controlled with the ALLNET ALL3505 IP Home Automation central unit. There are no limits to your ideas, from temperature recording and demand-oriented heating of individual rooms, control of garden irrigation, alarming in the event of gas odour and water ingress to automatic opening and closing of blinds depending on daylight and much more.

## **Accessible anywhere via network, Internet and smartphone**

You control everything from a PC, notebook or other mobile device, such as a smartphone or webpad. No matter whether the devices you want to control, measure, regulate are in the same building or on another continent. The ALLNET ALL3505 can be reached via an IP address. Your existing computer network and the Internet serve as the medium. The values determined can be called up directly from the device via the web browser or sent periodically by e-mail or if certain preset limit values are exceeded or not reached. An integrated XML interface is used for external data retrieval via the Internet.

## **Individually adapted to every requirement**

The ALLNET ALL3505 IP Home Automation Central Unit has a Linux based open source operating system. Thus it offers enough freedom for own developments and adjustments of the software directly on the purpose planned by the user.

## **GPL declaration**

The device contains software published under the GPL.

You can find the GPL online at [www.gnu.de](http://www.gnu.de).

et.de

## **The interfaces**

The following interfaces are available on the ALLNET ALL3505 IP DIN Building Automation Central Unit:

Eight sensor ports (RJ45), for connection of sensors, actuators, relays, etc.

One serial RS232 console port.

One USB 2.0 interface. These can be used to connect a USB memory stick, a UMTS/GPRS/GSM USB stick, a Plugwise or an EnOcean stick, for example.

Four contact inputs and an onboard temperature sensor (ALL3006 compatible) are already provided in the housing of the ALLNET ALL3505 IP Building Automation central unit.

choices

Modules of the ALL3000 and ALL4000 series can possibly be operated with the ALLNET ALL3505 IP Home Automation central unit. Many modules are also available as DIN rail versions.

#### Intelligent functions and programming via switching matrix

Depending on the values determined, certain actions can be programmed via the software switching matrix. For example, if the set limit values are exceeded or not reached, the measured values can be transmitted by e-mail, relays or sockets can be switched ON or OFF. This can be done once, several times and/or in certain time intervals, as long as the matrix condition exists. Internal variables are also available.

#### Flexible installation options

The external sensors are either plugged directly into the ALL3505 or can be set down and connected via a control cable/structured cabling. All ALLNET building automation products use a simple network cable (RJ45 connector, Cat. 5) for remote connection of the sensors to the central unit. For this purpose, however, an existing cable network, such as your own network or telephone cabling, can also be used. The maximum cable length between the central unit and module can be up to 100 meters. The modules are supplied with power by the central unit. A separate power source for the individual modules is not necessary.

#### Cross-location temperature recording without limits

In connection with further ALL3505, but also all other ALLNET control devices (ALL3418V2, ALL3000, ALL4000, ALL4500/5000) measuring networks can be created which are distributed over different locations. Each individual ALLNET measuring system is queried via the individual IP address and displayed and stored centrally in the ALL3505.

## initial operation

First connect the ALL3505 to the LAN cable, then the device to the 230V power supply.

The internal Linux operating system takes about 90 seconds to boot. (No activity can be performed during this time)

After the boot process is completed, the bus LED starts flashing. The ALL3505 can then be accessed via the WEB interface.

**Note:** After setting all network parameters, please execute the "Update Check" function.

## Adapting the ALL3505 to your network

### Establish initial connection with LAN cable

Connect your Ethernet Switch to your ALL3505 using the included LAN cable, making sure that the plugs engage audibly.

2 Connect the ALL3505 to the PC/MAC: The ALL3505 communicates with the connected components using the TCP/IP protocol. For the ALL3505 to be recognized by your PC/MAC, the PC/MAC and the ALL3505 must be in the same network segment.

By default, the ALL3505 has the following configuration data no:

IP address: 192.168.0.100


Subnet Mask: 255.255.255.0

No username or password required

Please set the PC or MAC temporarily to a free address between 192.168.0.1 - 192.168.0.254 (not 192.168.0.100 - this is already preset by the ALL3505 IP Home Automation central unit).

If you now enter the address 192.168.0.100 in the web browser (Internet Explorer, Firefox.etc...), the ALL3505 WEB sensor meters appear on the start page.

**Note:** Please do not connect any additional sensors for initial commissioning.





All displayed windows are caused by the internal sensors.

## LAN setup

### Setting the IP network address and LAN parameters

Enter the address of the ALL3505 IP Home Automation Central Unit in the web browser.  
Setting options under "Configuration" > "LAN Setting"



The screenshot shows the "Netzwerk Einstellung" (Network Settings) page. It features a blue header with the title "Netzwerk Einstellung". Below the header, there is a text input field containing "all3500" with the label "HOSTNAME". Below this, there are two radio buttons: "statisch" (selected) and "DHCP". Below the radio buttons, there is a label "IP ADRESS EINSTELLUNG". The page is divided into two sections: "Manuelle Netzwerk Einstellung" (Manual Network Settings) and "DHCP Einstellung" (DHCP Settings). The "Manuelle Netzwerk Einstellung" section contains five text input fields: "IP ADRESSE" (192.168.0.100), "NETMASK" (255.255.255.0), "DEFAULT GATEWAY" (192.168.0.1), "ERSTER DNS" (192.168.0.1), and "ZWEITER DNS" (8.8.8.8).

- a) **HOSTNAME:** Here you give your ALL3505 a name with which it is connected to the network. Only the following characters are valid: a-z, A-Z, 1-9 and hyphen (not to be used at the beginning or end). No special characters or spaces may be used. A maximum of 15 characters must be used.
- b) **IP ADDRESS SETTING:** When "DHCP" is selected, the ALL3505 IP Home Automation Central Unit uses an IP setting assigned by the DHCP server, points c. - g. are omitted. With "static" (default), the address is assigned manually.
- c) **IP ADDRESS:** Address of the ALL3505 in the network (Please make sure that you do not assign an IP address twice - ask your administrator if necessary).
- d) **NETMASK:** Default setting 255.255.255.0
- e) **DEFAULT GATEWAY:** Enter the default gateway, usually the IP address of your router.
- f) **FIRST DNS:** Enter the address of your DNS server here. For home networks, usually the IP address of your router.
- g) **SECOND DNS:** Default setting is 8.8.8.8 Please only change if there is a second DNS server in your internal network.


After changing the parameters, press "Save input". The ALL3505 will automatically restart. After approx. 90 seconds the ALL3505 should be accessible with the new parameters.

## WLAN setup

### Setting the WLAN parameters

Enter the address of the ALL3505 IP Home Automation Central Unit in the web browser.  
Setting options under "Configuration" > "WLAN Settings".

### WLAN Mode Selection



Select the operating mode for WLAN. There are 3 options available.

- Switched off. WLAN is disabled. (default setting)
- Access point. The ALL3505 works as a WLAN access point and provides WLAN access to all other devices.
- Wireless client. The ALL3505 can be connected to an existing WLAN.

## Access Point Settings

When using this mode in conjunction with a LAN, the ALL3505 serves as a WLAN access point. This allows other WLAN devices to be connected to your LAN.

This mode can also be used to control the ALL3505 standalone without LAN connection. For example, from your mobile phone via WLAN. It makes sense to activate the DHCP server for this operating mode. The description follows in a later chapter.

Wireless Einstellungen

Ausgeschaltet Access Point Wireless Client

WLAN MODE

ALL3500-AP1

SSID

0

KANAL

Offen Keine

WLAN AUTH MODE

12345678

CHIFFRIERSCHLÜSSEL  PASSWORT ANZEIGEN

Zeige Accesspoints Eingaben Speichern

When operating as an access point, you can use the displayed information by pressing the "Show Access Points" button to clearly differentiate yourself from the existing WLANs.

Now set your access data for your private wireless network.

SSID	Sicherheit	Signal %	Mode	Kanal
3p_Sender	WPA2PSK-AES	100	11b/g/n	1
wearetheborg	WPAPSK-AES	65	11b/g/n	1
OpenWrt	OPEN-NONE	60	11b/g/n	11
OxMox@Office	WPAPSK-AES	34	11b/g/n	6
FRITZIBox WLAN 3270	WPAPSK-AES	24	11b/g/n	1
rdwrt	WPA2PSK-AES	0	11b/g/n	4


Schliessen

Zeige Accesspoints Eingaben Speichern

a) **SSID:** Give the wireless network your own name.




- b) Channel: Select a free channel from the drop-down menu. You can recognize the occupied channels from the display of the "Show Access Points" function.




### Wireless Client Einstellung

Important ! If you use this operating mode, the LAN connection must be disconnected after the settings have been saved.



When operating as a wireless client, you can search and display the environment for existing WLAN access points by pressing the button "Search Access Points". To transfer the data of your WLAN simply, press the "Dial" button in the corresponding line. All data with the exception of the encryption key/WLAN password is transferred.



The parameters SSID, CHANNEL, WLAN AUTH MODE are automatically accepted by pressing the "Select" button. The "CHIFFRIER KEY" parameter must always be entered manually and must be identical to your already active WLAN.

Alternatively, you can manually set your access data for your private wireless network.

a) SSID: Entry must be identical to your WLAN.

b) WLAN AUTH MODE: Select the encryption method identical to your WLAN.

(OPEN NONE, Shared WEB, WPAPSK-TKIP, WPAPSK-AES, WPA2PSK-TKIP, WPA2PSK-AES).

c) CHIFFRIER KEY: Entry must be identical to your WLAN.

With "DISPLAY PASSWORD" you can visually check that no typing error has crept in.

After changing the parameters, press "Save input". The ALL3505 will automatically restart.

Now disconnect your ALL3505 from your LAN port. A simultaneous connection to WLAN and LAN leads to interference in your network (loop).

After approx. 90 seconds, the ALL3505 should be accessible with the new parameters via WLAN.

## DHCP server

Setting options under "Configuration" > "DHCP Server".

The ALL3505 can operate as a DHCP server. Activate this function only when the ALL3505 is operated as a stand-alone access point. **Caution:** If this function is activated and the ALL3505 is erroneously connected to your LAN, malfunctions will occur. For standalone operation, select an IP address that differs from the setting used in the existing LAN and WLAN, e.g. an address in the range 192.168.100.xxx

See also: [http://de.wikipedia.org/wiki/Private\\_IP\\_address](http://de.wikipedia.org/wiki/Private_IP_address)

The screenshot shows the DHCP Server configuration page. At the top right, there is a label "DHCP Server". Below it, there are two buttons: "Deaktiviert" (disabled) and "Aktiviert" (active). The text "DHCP SERVER MODUS" is visible. Below this, there is a section titled "DHCP Server Einstellungen". It contains several input fields: "IP ADDRESS RANGE BEGINNT BEI" (192.168.0.101), "IP ADDRESS RANGE ENDET BEI" (192.168.0.149), "NETMASK" (255.255.255.0), "GATEWAY" (192.168.0.1), "DNS 1" (194.25.2.129), "DNS 2" (212.18.0.5), and "DNS 3". At the bottom, there is a button labeled "Eingaben Speichern".

- a) DHCP Server Mode: Disabled / Enabled (Default = Disabled).
- b) IP Address Range starts at: The automatic assignment of IP addresses starts with xxx.xxx.xxx.xxx Default = 192.168.0.110
- c) IP Address Range ends at: The automatic assignment of IP addresses ends with xxx.xxx.xxx.xxx Default = 192.168.0.149
- d) Netmask: Default = 255.255.255.0 . Suitable for 192.168.xxx.xxx
- e) Gateway: Not relevant in standalone operation. Otherwise their router address.
- (f) DNA 1: Your DNS server address. For home networks, the router address) Not relevant for standalone operation.
- g) DNS 2: Not relevant in standalone operation.
- h) DNS 3: Not relevant in standalone operation.

## ALL3505 Configuration


Setting options under "Configuration" > "Device Settings".

All settings concerning the display and the behaviour of the device can be adjusted.

### Device Settings

The screenshot shows the 'Geräte Einstellungen' (Device Settings) page for an ALL3505 device. The interface is blue and white. At the top, there are two tabs: 'Geräte Einstellungen' (selected) and 'XML Fernsteuerung'. Below the tabs, the device name 'ALL3505' is entered in a text field, with the label 'GERÄTE NAME' below it. There are two numeric input fields for sensor display settings: the first is for the number of pages (set to 1) with the label 'ANZAHL DER SEITEN FÜR DIE DARSTELLUNG DER SENSOREN', and the second is for the number of columns (set to 3) with the label 'ANZAHL DER SPALTEN FÜR DIE DARSTELLUNG DER SENSOREN'. Below these are two more text input fields: 'ORTSÜBLICHER LUFTDRUCK' (set to 954) and 'AUFZEICHNUNGSINTERVALL FÜR DIAGRAMMDARSTELLUNG IN SEKUNDEN' (set to 120). There are two color pickers for 'FARBE FÜR ZUSTAND 'EIN'' and 'FARBE FÜR ZUSTAND 'AUS'', both set to '#ffffff'. Below the color pickers are two buttons: 'Deaktiviert' (selected) and 'Aktiviert'. There is also a section for 'EXPERTENANSICHT' with a 'Sensortafel' dropdown menu and a label 'STANDARD STARTSEITE FESTLEGEN'. At the bottom right, there is a 'Eingaben Speichern' (Save Inputs) button.

**Device Name:** This name is displayed at the top right of all web pages.



- a. **Number of columns:** The "Sensor Panel" web page is divided into the specified number. **Local air pressure:** The indication of the local air pressure is necessary to correct the display values of the pressure sensors. The sensors measure the absolute air pressure, but the display is usually in relative values. The local air pressure is influenced by the current altitude above sea level and local differences. You can find out the local air pressure at the responsible weather office. More information on the subject: <http://de.wikipedia.org/wiki/Luftdruck>.

- a. **Recording interval for diagram display:** The sensor values are transferred to the graphic display at the set interval.
- b. **Expert View:** This makes additional options visible on different pages. A change in the options that are then visible can have a lasting effect on functional reliability.
- c. **With different browsers the additional pages or changes on these are not displayed correctly or not at all.** Pressing the CTRL and F5 keys simultaneously clears the cache. The pages are then completely re-read and displayed without errors.
- d. **Set default home page:** You can select "Control panel" with display of the states of the actuators or "Sensor panel" with display of the sensors.

### XML Fernsteuerung

The screenshot shows a web interface for configuring XML remote control. At the top, there are two tabs: "Geräte Einstellungen" and "XML Fernsteuerung". Below the tabs, there are two buttons: "Deaktiviert" and "Aktiviert", with "Aktiviert" being the active state. Below these buttons is the text "XML FERNSTEUERUNG EINSCHALTEN". There are two input fields: the first is labeled "BENUTZERNAME" and the second is labeled "PASSWORT". At the bottom of the form is a button labeled "Eingaben Speichern".

- a. **Enable XML remote control:** Default = Deactivated. If the XML remote control is activated, the values of individual or all sensors can be queried by another system with XML commands, and thus actuators & other ALLNET switching products can be switched.
- b. **User name:** If this function is activated, a user name is required.
- c. **Password:**

## recording

These settings are only visible when the expert view is activated. Log messages can be sent to an external Syslog server. If the output to the Syslog server is activated, all log files of the activated daemons are sent to this Syslog server.

If the Syslog Server is deactivated, the log output of the individual daemons is done internally on the ALL3505 in the directory /tmp/wwwreports/. Access to the system console can be established either via the COM1 interface or via the network using a telnet program. The files can also be accessed via FTP.

SSL and FTP access settings in the chapter "WEB Server and Users" "FTP Server Setting / SSH Server Setting".

Geräte Einstellungen XML Fernsteuerung **Protokollierung**

Deaktiviert Aktiviert  
SYSLOG SERVER EINSCHALTEN

127.0.0.1  
SYSLOG SERVER IP

Aus 1 2 3 max  
LOGLEVEL OVERRIDE

5000  
MAXIMALE PROTOKOLLDATEI GRÖSSE (IN KB)

Aus 1 2 3 max  
SHM DAEMON PROTOKOLLERUNGS STUFE

Aus 1 2 3 max  
MATRIX DAEMON (AKTIONEN) PROTOKOLLERUNGS STUFE

Aus 1 2 3 max  
ALL3075 DAEMON PROTOKOLLERUNGS STUFE

Aus 1 2 3 max  
PLUGWISE DAEMON PROTOKOLLERUNGS STUFE

Aus 1 2 3 max  
POWERLINE DAEMON PROTOKOLLERUNGS STUFE

Aus 1 2 3 max  
ENOCLEAN DAEMON PROTOKOLLERUNGS STUFE

Aus 1 2 3 max  
MAILVERSAND PROTOKOLLERUNGS STUFE

Aus 1 2 3 max  
TIMER DAEMON (ZEITSTEUERUNG) PROTOKOLLERUNGS STUFE

Aus 1 2 3 max  
UPDATE PROTOKOLLERUNGS STUFE

Aus 1 2 3 max  
HISTORY DAEMON (AUFZEICHNUNG) PROTOKOLLERUNGS STUFE

Aus 1 2 3 max  
I2C DAEMON PROTOKOLLERUNGS STUFE

Aus 1 2 3 max  
DOWNLOAD DAEMON PROTOKOLLERUNGS STUFE

Aus 1 2 3 max  
CAMERA DAEMON PROTOKOLLERUNGS STUFE

Eingaben Speichern

- Switch on the Syslog server: Default = Deactivated.
- Loglevel Override: Log intensity setting for syslog log.
- Maximum log file size: Default = 5000KB
- Xxx Daemon Logging Level: Default = Off

**Important !** After troubleshooting, the setting for the log level should always be set to the default value "Off". An activated log report can impair system performance and stability.

Dienste Einstellungen

Setting options under "Configuration" > "Services Settings".

Services are installed on the ALL3505 for the integration of external actuators. This service connects to the actuators according to the selected parameters. These parameters are selected so that trouble-free operation is possible.

These settings are only visible if the expert view is activated in "Configuration Device Settings".

#### ALL3075

Access to external ALL307x actuators is via Ethernet.

The screenshot shows a configuration window for 'ALL3075 Dienst'. At the top, there are tabs for 'ALL3075 Dienst', 'Plugwise Dienst', 'enOcean', and 'System Daemons'. The 'ALL3075 Dienst' tab is selected. Below the tabs, there are two input fields. The first field contains the value '5' and is labeled 'VERZÖGERUNG ZWISCHEN ZUGRIFFEN (SEKUNDEN)'. The second field contains the value '3' and is labeled 'MAX. VERBINDUNGS VERSUCHE'. At the bottom of the window, there is a button labeled 'Eingaben Speichern'.

- Delay between accesses: Default = 5sec. This periodic access rate is used for communication with the external actuators; the ACTUAL state is compared with the TARGET state. Current state changes emanating from the ALL3505 are performed independently of this polling rate. This polling is performed for each external actuator, so do not set the access rate for complex systems too high.
- Max. Connection attempts: Default = 3 This value indicates how often the query is repeated without an error being displayed. If this sensor is not accessible, the polling rate is not interrupted.

#### Plugwise service


Communication with Plugwise is via the Zigbee radio standard. The corresponding Plugwise USB stick must be on the ALL3505 USB port before commissioning, otherwise the Linux service Plugwise will not run.

The screenshot shows a configuration window for 'Plugwise Dienst'. At the top, there are tabs for 'ALL3075 Dienst', 'Plugwise Dienst', 'enOcean', and 'System Daemons'. The 'Plugwise Dienst' tab is selected. Below the tabs, there are two input fields. The first field contains the value '/dev/plugwise|' and is labeled 'PLUGWISE SERIAL PORT'. The second field contains the value '5' and is labeled 'VERZÖGERUNG ZWISCHEN ZUGRIFFEN (SEKUNDEN)'. At the bottom of the window, there is a button labeled 'Eingaben Speichern'.

- Plugwise Serial Port: Default = /dev/ttyUSB0
- Delay between accesses: Default = 5

## EnOcean Service

The enOcean sensors are received via a required EnOcean USB stick. The EnOcean USB stick must also be plugged in here before commissioning the device.



ALL3075 Dienst Plugwise Dienst **enOcean** System Daemons


/dev/enocean  
ENOCEAN SERIAL PORT

Eingaben Speichern

EnOcean Serial Port: Default = /dev/enocean

## System Daemons

By changing these parameters, the query behaviour of the internal and external ALLNET sensors can be influenced.



ALL3075 Dienst Plugwise Dienst enOcean **System Daemons**

Deaktiviert **Aktiviert**  
AUTOMATISCHE SUCHE NACH NEUEN SENSOREN / AKTOREN

Deaktiviert **Aktiviert**  
SYNCHRONISATION MIT RTC

Deaktiviert **Aktiviert**  
STROMSPARFUNKTION FÜR SENSOREN

60  
RUHEZEIT

3  
AUFWACHZEIT

0  
ZEITVERZÖGERUNG ZWISCHEN MESSUNGEN

Eingaben Speichern


- Automatic search for new sensors: Default = Enabled.
- Synchronization with RTC: Default = Disabled. The interrogation of the sensors is synchronized by the internal clock.
- Power saving function for sensors: Default = Disabled. When using the ALL3505 in conjunction with a battery, power consumption can be reduced by activating.
- Rest time: Default = 60 seconds. With battery operation, the sensors are supplied with power every 60 seconds with this setting. The value can be extended to several days.
- Wake-up time: Default = 3 seconds. Depending on the number of sensors, it may be necessary to set this time longer. Only when the power save function is activated.
- Time delay between measurements: Default = 0 seconds.



## Setting the language

Setting options under "Configuration" > "Set language"

You can choose between German, English, Italian or Russian.



The screenshot shows a blue configuration panel with a title bar in the top right corner that reads "Wählen Sie Ihre Sprache". Below the title bar, there is a dropdown menu currently set to "Deutsch - German". Underneath the dropdown, the text "WÄHLEN SIE IHRE SPRACHE" is displayed. At the bottom center of the panel, there is a button labeled "Eingaben Speichern".

## SMTP Setting

Setting options under "Configuration" > "SMTP Setting".

It is possible that the ALL3505 will send emails to a given email address in case of different events.

Note: Only authenticated logins are allowed.



The screenshot shows a blue configuration panel with a title bar in the top right corner that reads "SMTP Einstellungen". The panel contains four input fields with labels below them: "smtp.testwelt.de" (SMTP SERVER), "ALL3505-1" (BENUTZERNAME FÜR DIE ANMELDUNG), a masked password field (PASSWORT FÜR DIE ANMELDUNG), and "ALL3505-1@testwelt.de" (ABSENDER ADRESSE). At the bottom center, there is a button labeled "Eingaben Speichern".

- SMTP server:** Enter IP address or email server name with domain.
- User name for login:** This username must exist on the server.
- Password for login:** Password must be entered.
- Sender address:** This is used for all outgoing emails.

## WEB Server and User Settings

Setting options under "Configuration" > "WEB Server and User".

### WEB Server Setting

Access to the web pages with configuration options can be blocked for normal users by using an admin user name.

Access to the normal WEB pages can be regulated by the use of a user name.

The screenshot shows a configuration window with three tabs: "Web server Einstellung" (selected), "FTP Server einstellung", and "SSH Server einstellung". The "Web server Einstellung" tab contains the following fields:


- Protocol selection: "http://" (selected) and "https://".
- Label: "BETRIEBSART MIT / OHNE SSL".
- Field: "80" with label "HTTP PORT NUMMER".
- Section header: "Benutzer Einstellungen".
- Field: "User1" with label "BENUTZERNAME".
- Field: "\*\*\*\*\*" with label "PASSWORT".
- Field: "Admin" with label "ADMIN BENUTZERNAME".
- Field: "\*\*\*\*\*" with label "ADMIN KENNWORT".
- Button: "Eingaben Speichern" at the bottom.

1. operating mode with / without SSL: Default = without
2. http port number : http = 80 / https = 443
3. username:
4. password:
5. Admin username:
6. Admin password:

**Note:** It makes sense to always make an entry for the admin user with password. In addition, an additional user name / password can be set up. It does not make sense to set up a user name / password alone, because otherwise all websites will remain unprotected due to the open admin access.

## FTP Server Setting

It is possible to access all files in the ALL3505 file system via FTP.



Web server Einstellung   **FTP Server einstellung**   SSH Server einstellung

**Aktiviert**   Deaktiviert

FTP SERVER AKTIVIEREN ODER DEAKTIVIEREN

21  
FTP PORTNUMMER

.....  
PASSWORT FÜR BENUTZER: ftp

Eingaben Speichern

1. activate FTP server: Default = enabled
2. FTP port number: Default = 21
3. Password for user ftp: When logging in, lowercase the user name "ftp". The password is transmitted unencrypted.

## SSH Server Setting

Advanced users can directly access the console of the Linux operating system.



Web server Einstellung   FTP Server einstellung   **SSH Server einstellung**

**Aktiviert**   Deaktiviert

SSH SERVER AKTIVIEREN ODER DEAKTIVIEREN

.....  
PASSWORT FÜR BENUTZER: root

Eingaben Speichern

1. activate SSH server: Default = enabled
2. SSH port number = 22
3. password for user root: When logging in, lowercase the user name "root".

**!! This password should be changed!**

## Date and time

Setting options under "Configuration" > "Date and time"

The ALL3505 usually synchronizes its system time via an NTP server. The NTP time is requested at boot time and every 24 hours. the request is made via port 123. this port must be stateful open at the firewall. An internal network time server can also be used. Your DSL router may also work as an NTP server. Then enter your DSL router in NTP Server 1.

For a correct time the ALL3505 must have a working internet connection!

The screenshot shows the 'Date and time' configuration page. At the top right, there is a 'Zeitserver' tab. The main area is divided into several sections:

- Time Zone:** A dropdown menu is set to 'GMT+1'. To its right is an 'Aktiviert' button and the text 'AUTOMATISCHE SOMMERZEIT UMSCHALTUNG AKTIVIEREN ODER DEAKTIVIEREN'.
- Time Server:** A section with 'Aktiviert' and 'Deaktiviert' buttons, and the text 'ZEITSERVER AKTIVIEREN ODER DEAKTIVIEREN'.
- NTP Server 1:** Input field containing 'ptbtime1.ptb.de'.
- NTP Server 2:** Input field containing 'ptbtime2.ptb.de'.
- NTP Server 3:** Input field containing 'ntp0.fau.de'.
- NTP Server Pool:** Input field containing 'pool.ntp.org'.
- Time Display:** A section with a warning 'Zeit Anzeige (kann nur geändert werden wenn der Zeitserver deaktiviert ist)'. It contains two input fields: '06:13:32' for 'SYSTEM ZEIT' and '01.01.1970' for 'SYSTEM DATUM'.

At the bottom center, there is a 'Eingaben Speichern' button.

- a. Time zone: GMT-12 to GMT-14
- b. Activate daylight saving time: Default = Enabled.
- c. Activate or deactivate time server: Default = Enabled.
- d. NTP Server 1-3: Selection of possible time servers. Alternatively, set local time server (DSL router) in first place.
- e. NTP server pool:
- f. System Time: A manual setting of the system time and date is only possible with deactivated time server client.
- g. System Date:

**Note:** Setting the system time manually makes little sense, since the ALL3505 has no battery backup for the real-time clock, and therefore the system time is always set to 00:00 o'clock on 01.01.1970. Therefore, please make sure that the time server is accessible and correctly set.

## Device Status

Setting options under "Configuration" > "Device Status"

The website gives an overview of the system:

- Software version
- Hardware version
- MAC address
- storage allocation
- System Date Time
- service life
- Services Overview

The screenshot displays the 'Device Status' web interface with the following sections:

- Version:** SOFTWARE 3.00.00, HARDWARE 0.02, MAC 00:0F:C9:0B:51:A3
- System Info:** A table showing storage and system details.

GESAMT	BELEGT	FREI	GERÄTESPEICHER
60844 kB	30812 kB	30032 kB	9.81 MB
SYSTEM INFO			BETRIEBSZEIT
01.01.1970 - 01:50:29			50 min
- Dienste:** A list of running services: all3075\_demon, download\_demon, history\_demon, i2c\_demon, matrix\_demon, sensor\_shm\_demon, timer\_demon, and update\_demon, all with status 'läuft'.
- Konfiguration Sichern / Wiederherstellen:** Buttons for 'Konfiguration Sichern', 'Konfiguration Laden', 'Durchsuchen', and 'Hochladen'.
- Gerät Neustarten / Zurücksetzen auf Werkseinstellung:** Buttons for 'Neustart' and 'Werkseinstellungen'.

The following settings and functions are available:

- Save Configuration: Saving a configuration backup file.
- Load / Browse configuration: Transports the configuration to be activated to the ALL3505.
- Upload: Activates the configuration loaded with "Load configuration".
- Restart: Restart the system.
- Factory setting: Reset all parameters. A confirmation prompt follows.

## Update settings

### Setting options under "Configuration" > "Update Settings"

It is possible to manually check for and install updates immediately. The ALL3505's factory setting automatically checks for updates every system startup and once every 24 hours. Optionally, it is possible to load a firmware file directly.

The screenshot shows the 'Update Settings' interface for the ALL3505 device. It is divided into three main sections:

- Version:** Displays device information: DEVICE: ALL3418, HARDWARE: 0.02, SOFTWARE: 3.00.00, MAC: 00:0F:C9:0B:51:A3. It includes buttons for 'Update Prüfung' and 'Installierte Patches/Updates'.
- Automatische Aktualisierung:** Features a toggle switch currently set to 'Ein' (On) and the text 'AUTOMATISCHE AKTUALISIERUNG'.
- Firmware Aktualisierung:** Includes a 'Patch Datei' input field, a 'Durchsuchen' (Browse) button, and a 'Hochladen' (Upload) button.

- Update Check:** Manually trigger a check for updates on the ALLNET Update Server.
- Installed patches / updates:** Displays installed patches and updates. With respective installation date.
- Automatic update:** Default = On
- Patch File / Browse:** Patch files can be transported to the ALL3505.
- Upload:** The loaded patches are installed.

## Download the manual

### Possibility under "Configuration" > "Load manual" (example)

The screenshot shows a file download dialog box with the following text: 'Möchten Sie "ALL3073\_de.pdf" (218 KB) von "docs.allnetnetworks.com" öffnen oder speichern?'. The dialog includes three buttons: 'Öffnen', 'Speichern', and 'Abbrechen', along with a close button (X).

Depending on the previous language selection in the interface, the download of the manual is started in the corresponding language.



## functionalities

### actuators

Setting options under "Functions" > "Actuators"

The ALL3505 has 4 internal switching relays with which loads up to 8A can be switched. In addition, the ALL3505 can be expanded with other ALLNET switching actuators such as ALL3073 / ALL3075 / ALL3075V2, ALL3075WLAN and other radio standards such as Plugwise/EnOcean actuators. These devices are listed as actuators and can control/switch a load and measure possible current consumption. ALL3075V2 & ALL3075WLAN can display the current power consumption in addition to the switching process. Communication is either via LAN or WLAN. With Plugwise Zigbee is used for communication, the USB stick contained in the Plugwise Starterkit is plugged into the USB socket of the ALL3505.

### Managing internal actuators




Interne Aktoren können nur Aktiviert oder Deaktiviert werden.




- Actuator name: This name is displayed on the control panel. The length of the text field is limited to 20 characters.
- Actuator Description: This description is for information only.

## Creating an external actuator



Press "+" to create a new actuator.

## Selecting an actuator



1. activate or deactivate: This allows actuators that have already been created to be deactivated.
2. device type: Select in scroll down procedure.



1. select ICON/View: You can see a selection by clicking on the ICON.
2. Delete this actuator: This selection only appears for actuators that have already been created.



## Actor Parameter

Aktor Parameter Sicherheit

192.168.6.122  
ALL3075V2 IP ADRESSE

All3073-1  
AKTOR NAME

Stehlampe WZ  
AKTOR BESCHREIBUNG

Zurück zur Liste Eingaben Speichern

1. actuator IP address: Each actuator has its own IP address. Enter this address here.
2. actuator name: Choose a name suitable for the task. This name is displayed on the main page.
3. actuator description: The description is for detailed information but is not displayed on the main page.

## Aktor Sicherheit

Aktor Parameter Sicherheit

ALL3505  
BENUTZERNAME

\*\*\*\*\*  
PASSWORT

Zurück zur Liste Eingaben Speichern

- a) User name: Only if you have assigned a user name to the actuator itself, this must be entered here.
- b) Password: Only if you have assigned a user name on the actuator itself, the password must also be entered here.

## Actuator Delete

Aktor Parameter Sicherheit

Aktiviert Deaktiviert

Diesen Aktor Löschen

AKTOR AKTIVIEREN ODER DEAKTIVIEREN

ALL3073  
GERÄTE TYP

ICON AUSWÄHLEN

Zurück zur Liste Eingaben Speichern

Delete this actuator: This option is only available for actuators that have already been created.

## Virtual Sensors


Virtual sensors offer a wide range of possibilities for displaying values. The outputs of several sensors can also be combined. Virtual sensors can have the task of variables. Complex control networks can be built up in this way. The result of a virtual sensor is displayed on the main page in the same way as a sensor. The output can also be suppressed, the output value can be used for further operations.

### Creating Virtual Sensors



To create a new virtual sensor, press "+".

### Creating a virtual sensor



1. Sensor Name: This name is displayed on the sensor panel. The length of the text field is limited to 20 characters.
2. Sensor Description: Description for information purposes only.
3. Select function: System variables or calculation and comparison operators are available.
4. System variables: Hour, minute, second, CPU load.
5. Calculation: addition, subtraction, multiplication, division.
6. Logical operators: AND, OR, XOR, ABS(), only >0.

## Configuring the virtual sensor

The screenshot shows a configuration page for a virtual sensor. At the top right, there is a blue tab labeled "Virtueller Sensor". Below it, a button reads "Diesen Virtuellen Sensor Löschen". The main configuration area is divided into several sections: 1. A text input field containing "Alarm auslösen" with the label "SENSOR NAME" below it. 2. Another text input field containing "Variable für Alarmauslösung" with the label "SENSOR BESCHREIBUNG" below it. 3. A section for the sensor type and unit, with a dropdown menu set to "Berechnung: AND" (labeled "ART DES VIRTUELLEN SENSORS") and an empty text input field (labeled "MESSEHHEIT"). 4. A section for conditions, with a dropdown menu set to "Schalteingang 2" and a button "Alarm aktivieren". 5. A central area with a logical symbol (an upward-pointing triangle above an equals sign) and the text "ERGEBNIS WIRD IN NEUEN VIRTUELLEN SENSOR DARGESTELLT". At the bottom, there are two buttons: "Zurück zur Liste" on the left and "Eingaben Speichern" on the right.

- a) Delete virtual sensor: This option is only available after the first saving.
- b) Sensor Name:
- c) Sensor Description
- d) Type of virtual sensor (operator):
- e) Unit of measurement: Text field
- f) Condition 1: Sensors or virtual sensors can be selected.
- g) Condition 2:

## XML Sensors

XML-enabled devices can be queried by XML sensors. XML-enabled devices that can be accessed via the Internet can also be integrated into the functions of the ALL3505.

## activities

Under "Actions" you can program the triggering of actions. Actuators can be switched and or emails can be sent. The system status can also be time-controlled or a boot email can be sent. A total of 32 switching points can be set.



A new switching point is created by clicking the "+" sign.

## Alarm

Alarm

Vergleichen

Aktion

eMail Benachrichtigung

Status Benachrichtigungen

Aktiviert

Deaktiviert

ALARM

Ü-Temp\_SRV-Rack\_1

BEZEICHNUNG

Übertemperatur Server Rack 1

BESCHREIBUNG

Zurück zur Liste

Eingaben Speichern

- Alarm: Enabled / Disabled. Created switching points can thus be temporarily deactivated.
- Name: Maximum 20 characters. The designation is displayed in the table of switching points.
- Description: Provides a comprehensive description.
- Delete alarm: This menu item only appears after saving.

## Compare

Alarm

Vergleichen

Aktion

eMail Benachrichtigung

Status Benachrichtigungen

Intern

Benutze Konstante

SENSOR WÄHLEN

VERGLEICHS SENSOR WÄHLEN

>

BEDINGUNG

28

KONSTANTE

Zurück zur Liste

Eingaben Speichern

- Select sensor: All already created sensors can be selected.
- Select comparison sensor: You can choose between sensor or constant.
- Condition: operators < <= = >= > <>
- Constant: Values with or without decimal point can be entered.

## campaign

Alarm | Vergleichen | **Aktion** | eMail Benachrichtigung | Status Benachrichtigungen

ALL3075V2\_1 Ein Aus Umschalten  
AKTOREN AKTOR AKTION

Name des Scripts inkl. Pfad. (zB. /data/beispiel.sh)

SCRIPT ZUM STARTEN

Aktiviert Deaktiviert  
NUR EINMAL AUSFÜHREN

ALARM PAUSE (SEKUNDEN)

Zurück zur Liste Eingaben Speichern

- Actuators: All already created actuators can be selected.
- Actuator action: On / Off / Switch.
- Script to start: Optionally, the ALL3505 must have a Linux shell script that is started by this call. This function
- Execute only once: If this switch is activated, the action is executed exactly once when the threshold value is reached. If the switch is deactivated, the action is executed continuously (usually 10 times per second).
- Alarm pause (seconds): Default = 1 second The switching rule is ignored after triggering before it is switched back on. (similar to the HOLDOFF setting of an oscilloscope)

## eMail Notification

Alarm | Vergleichen | Aktion | **eMail Benachrichtigung** | Status Benachrichtigungen

Aktiviert Deaktiviert  
EMAIL VERSAND

Alarm@allnet.de  
EMAIL EMPFÄNGER

ALL3418  
EMAIL BETREFF

Alarm Alarm die Bude brennt  
EMAIL TEXT


Kein Wert Einzel Wert Alle Werte  
SENDE SENSORWERTE IM EMAIL TEXT

Zurück zur Liste Eingaben Speichern

- Email dispatch: Activated / Deactivated
- Email recipient: name@adresse.xx
- Email Subject:
- Email text:
- Send sensor values in the email: Selection of the display values to be sent.

## Status Notifications

Email notifications about the system status can be executed. Enabling these notifications disables all other settings.



The screenshot shows a web interface for configuring status notifications. At the top, there is a navigation bar with five tabs: 'Alarm', 'Vergleichen', 'Aktion', 'eMail Benachrichtigung', and 'Status Benachrichtigungen'. The 'Status Benachrichtigungen' tab is currently selected and highlighted in orange. Below the navigation bar, there is a main content area with a blue background. At the top of this area is a dropdown menu with 'System Status' selected. Below the dropdown is the text 'STATUS AUSWÄHLEN'. Underneath that is a long, empty text input field. Below the input field is the text 'VERSANDZEIT'. At the bottom of the main content area, there are two buttons: 'Zurück zur Liste' on the left and 'Eingaben Speichern' on the right.

- a) Select status: A boot email or system status can be sent.
- b) Shipping time: If System Status is selected, a daily time can be set.


## timing

### Setting options under "Functions" > "Time control"

Time-dependent switching points can be created. The resolution is 1 second. A maximum of 128 switching points can be defined.



After clicking the plus sign, the mask for setting up a new switching point opens automatically.



1. switching point activation / deactivation.
2. switching point name: Select a name suitable for the switching point. This name is displayed in the overview page.
3. switching point description: The description is for detailed information but is not displayed on the overview page.

4. Start time: Select the desired time with the three sliders.

**Startzeit wählen**

Zeit 13:00:00

Stunde 00 04 08 12 16 20

Minute 00 05 10 15 20 25 30 35 40 45 50 55

Sekunde 00 05 10 15 20 25 30 35 40 45 50 55

Jetzt Auswählen

5. Action: On / Off. If "On" is selected, the relay is closed at this moment. For various tasks, it may be necessary for the relay to open to the starting point, but "Off" can be selected.
6. active on weekdays: selection by clicking.
7. actuator selection: Select the desired actuator with the scroll down menu.

After saving, all timers are displayed in the overview.

GARTENBEWÄSSERUNG	07:00:00 EIN	GARTENBEWÄSSERUNG
GARTENBEW. ABSCH.	08:00:00 AUS	GARTENBEWÄSSERUNG ABSCHALTEN.
ROLLO RÜCKS. SCHL.	22:00:00 EIN	ROLLO KELLERFENSTER
ROLLO RÜCKS. ÖFFNEN	07:00:00 EIN	ROLLO KELLERFENSTER ÖFFNEN

Aktiviert

+



## Recording

The screenshot shows a configuration interface for recording. It is divided into three main sections: 'Messwert Aufzeichnung', 'Sensorauswahl', and 'Datensicherung'. At the bottom, there is a 'Eingaben Speichern' button.

- Messwert Aufzeichnung:** Contains a toggle for 'Aktiviert' (selected) and 'Deaktiviert'. Below it is the text 'AUFZEICHNUNG IN DATEI AKTIVIEREN'. A dropdown menu shows 'alle 5 Minuten' with the label 'AUFZEICHNUNGS INTERVAL' below it.
- Sensorauswahl:** Contains two buttons: 'Alle Auswählen' and 'Auswahl aufheben'. Below them is a warning: 'HINWEIS: Wenn Sie eine bestehende Sensorauswahl ändern, wird die bestehende Aufzeichnung gelöscht! und neu angelegt.' There are nine checkboxes arranged in a 3x3 grid, each labeled 'ANSCHLUSS 0', 'SCHALTEINGANG 0', or 'SENS1 DIAGRAMM'.
- Datensicherung:** Contains a 'Herunterladen' button with the text 'DATEI MIT DEN DEN AUFGEZEICHNETEN WERTEN HERUNTERLADEN' below it. Below that is a 'Löschen' button with the text 'DATEI MIT DEN DEN AUFGEZEICHNETEN WERTEN LÖSCHEN UND GGF. NEU ANLEGEN' below it.

## Camera Upload

This function only supports Mobotix cameras. The selected sensor values are displayed in the camera image. This allows you to create an application: weather station with image upload.

The screenshot shows a configuration interface for camera upload. It has a header with three tabs: 'Kamera' (selected), 'Adresse', and 'Parameter'. Below the header is a toggle for 'Aktiviert' (selected) and 'Deaktiviert' with the text 'UPLOAD AKTIVIEREN / DEAKTIVIEREN'. There are two text input fields: the first contains 'Hofeinfahrt Überw.' with the label 'KAMERA NAME' below it, and the second contains 'Hofeinfahrt Überwach|' with the label 'KAMERA BESCHREIBUNG' below it. At the bottom, there are two buttons: 'Zurück zur Liste' and 'Eingaben Speichern'.

- Activate Upload:
- Camera Name: This name is displayed in the overview.
- Camera Description: Description for information purposes only.

- a) Camera address: Enter IP address or DNS name.
- b) Transmission interval: Default = 30.
- c) User name:
- d) User password:


- a) Top text:
- b) Text of enterprises
- c) Transfer time stamp: Default = Deactivated
- d) Sensor for value 1-6:

home page

sensor panel


The current sensor values are displayed on the main page of the sensor panel. The layout and color scheme have been defined in the chapter entitled "Configuration" > "Device Settings".

The sensors already integrated in the device can be found automatically in the sensor panel.



## Setting up new sensors

It is recommended to set up the sensors only after the basic installation of the ALL3505. Ideally, only one new sensor is connected to the ALL3505 at a time, making assignment and naming easier. Various sensors/actuators can be connected. Example ALL3006, ALL3018, ALL4529 The time until a new sensor is detected can take several minutes.



The screenshot shows the ALLNET web interface. At the top left is the ALLNET logo. Below it is a navigation bar with 'Hauptseite', 'Funktionen', and 'Konfiguration'. The main content area displays a temperature reading of 42.43 °C for an 'Intern' sensor, with a range of [-49.5] to [135]. Below the temperature reading is a notification box titled 'Neue Sensoren gefunden' (New sensors found) with the question 'Möchten Sie diese jetzt einrichten?' (Do you want to set these up now?). It also provides instructions: 'Wenn Sie die Sensoren Später einrichten möchten, finden Sie die neuen Sensoren unter dem Menüpunkt 'Neue Sensoren'.' (If you want to set up the sensors later, you will find the new sensors under the menu item 'New Sensors'). There are two buttons: 'Später' (Later) and 'Ja' (Yes). At the bottom right, there is a copyright notice: 'Copyright © 2012 Allnet Deutschland GmbH'.

As a rule, the sensors are integrated automatically. If the sensor cannot be assigned automatically, a manual assignment is necessary. For some sensors there are different options that can be configured via a separate selection window.




The screenshot shows the ALLNET web interface with a notification: 'Folgende Sensoren wurden Automatisch angelegt' (The following sensors were automatically created). Below this is a table with the following data:


Geräte Anschluß	Multiplexer Anschluß	Sensor Beschreibung	Sensor Funktion
0	0	Temperatursensor	Temperatur
0	0	Feuchtigkeitssensor	Luftfeuchte

Below the table, it says: 'Die Sensortafel wird in 6 sek. Automatisch neu geladen' (The sensor panel will be automatically reloaded in 6 seconds).

These sensors contained in this list were detected automatically.



After returning to the sensor panel, the newly detected sensors are listed.



The sensor window can be moved by clicking with the mouse in the area of the labeling.



## Sensor configuration



Click the tool icon to configure the new sensors.

Sensor | Darstellung | Limit | System / Bus | Min / Max | Berechnung | Duplizieren

Information

Aktiviert | Deaktiviert

SENSOR ANZEIGEN

Intern

SENSOR NAME

Temperatursensor

SENSOR BESCHREIBUNG

Abbrechen | Eingaben Speichern

1. information: output of sensor inventory data. See picture below.

Sensor | Darstellung | Limit | System / Bus | Min / Max | Berechnung | Duplizieren

Information


Chip Beschreibung: Temperatursensor  
Chip Funktion: Temperatur  
Geräte Artikelnr.: ALL4406, ALL3007  
Meßeinheit: °C  
Sensor Meßbereich: [-55] - [150]  
Interne Sensor Id: 1  
Chip Id: 2  
Chip Nummer: 2  
Chip Adresse Min: 0  
Chip Adresse Max: 3  
Geräte Anschluß: 4

Abbrechen | Eingaben Speichern


2. sensor displays: Default = Enabled, If Disabled is selected, the sensor no longer appears on the sensor panel. A logical evaluation of the signal is still possible.
  3. Sensor Name: This name is displayed on the sensor panel. The length of the text field is limited to 20 characters.
  4. sensor description: The text is for information only.
- a) Note: Hidden sensors can be reactivated under "Hidden Sensors" on the main page. This option is only visible when sensors are disabled.



**Sensor Display**



Display of the sensor: There are three types of display (see below)




**Text**

**Instrument**

**Diagramm**

## Text


Display in Textform.



1. select display of the sensor: (text)
2. Minimum and maximum value: The display shows/selects the minimum and maximum values.
3. color change on over/underrange: The background around the instrument is highlighted when exceeding or falling below the setpoints.

tool

Display in analog instrument form .



- a) select display of the sensor: (instrument)
- b) change colour at over / undercut: The background color of the instrument changes when the value exceeds or falls below a setpoint. Setpoint is defined under Limit.
- c) Select the instrument type for the display: There are 5 types to choose from.




- d) LCD for value display: In addition to the pointer display, the value is displayed as a digital number.
- e) section markings:
- f) marking threshold:
- g) marking area:

chart

Display in diagram form .



- a) select display of the sensor: (diagram)
- b) change colour at over / undercut: The background color of the diagram display changes when a setpoint is exceeded or not reached. Setpoint is defined under Limit.
- c) Select the color for the graph:



- d) fill up to the axle: The display is executed as an area.
- e) lower threshold value: Default = Display. Color can be selected.
- f) upper threshold value: default = display. Color can be selected.

## limit

The start and end values of the display can be set, as can the values for the display of the lower and upper threshold values.

The screenshot shows a software interface with a top navigation bar containing buttons for 'Sensor', 'Darstellung', 'Limit' (highlighted), 'System / Bus', 'Min / Max', 'Berechnung', and 'Duplizieren'. Below this is an 'Information' tab. The main area contains four input fields with labels and values:

- Input field: 0, Label: SENSOR ANZEIGE MINIMALWERT, Unit: [0]
- Input field: 1200, Label: SENSOR ANZEIGE MAXIMALWERT, Unit: [1200]
- Input field: 1, Label: SENSOR UNTERER SCHWELLENWERT
- Input field: 1080, Label: SENSOR OBERER SCHWELLENWERT

At the bottom, there is a slider control for 'DURCHSCHNITTSWERT ÜBER 0 MEßWERTE BILDEN.' and two buttons: 'Abbrechen' and 'Eingaben Speichern'.

- Sensor display minimum value:
- Sensor Display maximum value:
- Sensor lower threshold value:
- Upper threshold sensor:
- Calculate the average value over measured values: Settings: Off or 1 - 100.

## System / Bus

This display only appears when the expert view is activated in the "Device Settings" menu.

Sensor Darstellung Limit **System / Bus** Min / Max Berechnung Duplizieren

Information

BUS GESCHWINDIGKEIT 50

CHIP ADRESSE 0

Niedrig **Normal**

PRIORITÄT

Abbrechen Eingaben Speichern

- Bus speed: If the sensor is operated with a longer cable, it may be necessary to reduce the speed. The higher this value is, the slower the bus is clocked.
- Chip address: The address can be set manually on various sensors.
- If this is subsequently changed on the sensor, this parameter must be adjusted.
- d)** Priority: All sensors with "Normal" priority are scanned every second. For sensors with low priority, only one sensor with normal priority is queried at a time following the sensors. This means that with 10 sensors with low priority, each sensor is only read again every 10 seconds. The low priority relieves the device and can improve the reaction speed when building a website. In addition, temperature sensors work more accurately because self-heating is reduced by the measuring process.

## Min / Maximum value

The minimum and maximum values of a day and the values over the entire runtime are displayed.

Sensor Darstellung Limit System / Bus **Min / Max** Berechnung Duplizieren

Information

Tages Meßwerte

Minimalwert: 1011.28 hPa gemessen am 23.01.2013 um 08:39:51  
Maximalwert: 1011.28 hPa gemessen am 23.01.2013 um 08:40:05

Zurücksetzen

Absolute Meßwerte

Minimalwert: 1011.28 hPa gemessen am 23.01.2013 um 08:39:51  
Maximalwert: 1011.28 hPa gemessen am 23.01.2013 um 08:40:01

Zurücksetzen

Abbrechen Eingaben Speichern

## reckoning

Used to adjust the sensor values displayed or used in virtual sensors. By activating this calculation, the sensor value can be scaled or offset.

The screenshot shows a software window with a top navigation bar containing buttons for 'Sensor', 'Darstellung', 'Limit', 'System / Bus', 'Min / Max', 'Berechnung' (highlighted in orange), and 'Duplizieren'. Below the navigation bar is a tab labeled 'Information'. The main content area has a blue background and contains the following elements:

- Two buttons: 'Aktiviert' (grey) and 'Deaktiviert' (orange).
- Text: 'BERECHNUNGSFUNKTION AKTIVIEREN / DEAKTIVIEREN'
- Text: 'BEISPIEL:'
- Equation 1:  $(\text{SENSOR WERT} + \text{ADDITION 1}) * \text{MULTIPLIKATION 1} = \text{NEUER WERT}$  (31,10 + 10) \* 2 = 82,2
- Equation 2:  $((\text{SENSOR WERT} + \text{ADDITION 1}) * \text{MULTIPLIKATION 1}) * \text{MULTIPLIKATION 2} = \text{NEUER WERT}$  ((31,10 + 10) \* 2) \* 2) = 164,4
- Input field for 'ADDITION 1' containing the value '0'.
- Input field for 'MULTIPLIKATION 1' containing the value '1'.
- Input field for 'ADDITION 2' containing the value '0'.
- Input field for 'MULTIPLIKATION 2' containing the value '1'.

At the bottom right of the window are two buttons: 'Abbrechen' and 'Eingaben Speichern'.

## duplication

By duplicating a sensor can be used several times. As an example, a representation as an instrument and as a diagram is to be displayed on the main page at the same time.

The screenshot shows a software window with a top navigation bar containing buttons for 'Sensor', 'Darstellung', 'Limit', 'System / Bus', 'Min / Max', 'Berechnung', and 'Duplizieren' (highlighted in orange). Below the navigation bar is a tab labeled 'Information'. The main content area has a blue background and contains the following elements:

- Input field containing the text 'Sens1 Diagramm|', with the label 'SENSOR NAME FÜR DUPLIKAT' below it.
- Button: 'Sensor Duplizieren'
- Text: 'ES WIRD 1:1 KOPIE DES GEWÄHLTEN SENSORS ANGELEGT'

At the bottom right of the window are two buttons: 'Abbrechen' and 'Eingaben Speichern'.

#### **reset**

**It can happen that your ALL3505 is no longer accessible due to incorrect user settings, that a password has been set and forgotten, etc.. In this case, you can use the following reset procedure to reset all settings in the device back to the factory settings (all settings and values are lost): Disconnect the device from the power supply. Using a non-conductive pointed object (e.g. a toothpick), press and hold the RESET button through the small hole next to the USB slot (the button must remain pressed!). Now supply the ALL3505 with power and wait approx. 3 minutes until the BUS LED starts flashing. Release the button NOW. After this, the reset process is complete and all settings are back in the factory settings.**

#### **cleaning**

**Always unplug the power supply unit from the mains socket before cleaning the device.**

**When cleaning, use a slightly damp and soft cloth (preferably an microfibre cloth). Never use cleaning agents, alcohol or other solvents for cleaning. Please note that the housing contains modern electronics. Never use so much water or cleaning agent that it can penetrate through the side ventilation slots (holes) or through the small gaps between the metal frame or through the recesses in the connections into the interior of the ALL3505. If it does happen, please do not reconnect the device and contact our support.**

## Technische Daten

External connections:	8x RJ45 Sensor/Actuator-Ports
	1x RS232 Console
	1x USB 2.0
Internal connections:	1x Temperature sensor onboard
Network:	1x RJ45 Ethernet 10/100BaseTX
	2,4 GHz Wireless N, bis zu 150 Mbps nach IEEE802.11b/g/n
Network Protocols:	HTTP/HTTPS, TCP/IP, NNTP, SMTP, FTP, SSH
Operating systems:	alle netzwerkfähigen Betriebssysteme
power supply	external 12V DC 1A power supply Power consumption approx. <3W (without additional modules)
Dimensions and weight:	106 * 90 * 60mm (Breite * Höhe * Tiefe)
	300g
	PC/ABS DIN-rail housing
Temperature operation:	0 - 50°C
Humidity	10% - 85% (non-condensing)
Temperature storage:	-20 - 60°C
Storage of humidity:	5% - 90% (non-condensing)
Certification	CE, RoHS

## **ALLNET GPL Code Statement**

This ALLNET product includes software code developed by third parties, including software code subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL"). As applicable, the terms of the GPL and LGPL, and information on obtaining access to the GPL code and LGPL code used in this product, are available to you at:

<http://www.allnet.de/gpl.html>

The GPL code and LGPL code used in this product is distributed WITHOUT ANY WARRANTY and is subject to the copyrights of one or more authors. For details, see the GPL code and the LGPL code for this product and the terms of the GPL and LGPL.

## **Written offer for GPL and LGPL source code**

Where such specific license terms entitle you to the source code of such software, ALLNET will provide upon written request via e-mail and/or traditional paper mail the applicable GPL and LGPL source code files via CD-ROM for a nominal cost to cover shipping and media charges as allowed under the GPL and LGPL.

Please direct all inquiries to:

Email:  
[support@allnet.de](mailto:support@allnet.de)

Snail Mail:  
ALLNET GmbH  
Maistraße 2  
82110 Germering

## **GNU GENERAL PUBLIC LICENSE**

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

## **Preamble**

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

## **GNU General Public License**

### **Terms and conditions for copying, distribution and modification**

**0.** This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or



a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

**3.** You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

**4.** You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

**5.** You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

**6.** Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

**7.** If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

**8.** If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

**9.** The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

**10.** If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### **NO WARRANTY**

**11.** BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

**12.** IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

## **How to Apply These Terms to Your New Programs**

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

one line to give the program's name and an idea of what it does.

Copyright (C) yyyy name of author

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2

of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

```
Gnomovision version 69, Copyright (C) year name of author
Gnomovision comes with ABSOLUTELY NO WARRANTY; for details
type `show w'. This is free software, and you are welcome
to redistribute it under certain conditions; type `show c'
for details.
```

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright

interest in the program `Gnomovision'

(which makes passes at compilers) written

by James Hacker.

signature of Ty Coon, 1 April 1989

Ty Coon, President of Vice

Source: <http://www.gnu.org/licenses/old-licenses/gpl-2.0>



## CE-Declaration of Conformity

For following equipment:

Germering, December 13, 2013

### ALL3505 IP DIN rail Automation Gateway



This equipment conforms with the requirements of the Council Directive **R&TTE 1999/519/EC** on the approximation of the laws of the member states relating to Radio and Telecommunication Terminal Equipment and the mutual recognition of their conformity.

The safety advice in the documentation accompanying the products shall be obeyed. The conformity to the above directive is indicated by the CE sign on the device.

The ALL3505 IP DIN rail automation gateway conforms to the European Directives EMV 2004/108/EG

This equipment meets the following conformance standards:

<b>EN 50385: 2002</b>	<b>EN 300 328 V1.7.1 (2006-10)</b>
<b>EN 301 489-1 V1.8.1 (2008-04)</b>	<b>EN 301 489-17 V2.1.1 (2009-05)</b>
<b>EN 55022: 2006+A1: 2007, Class B (Conducted Emission Test)</b>	
<b>EN 61000-3-2: 2006+A1: 2009+A2: 2009, Class A</b>	
<b>EN 61000-3-3: 2008</b>	<b>EN 61000-4-2: 2009</b>
<b>EN 61000-4-3: 2006+A1: 2008</b>	<b>EN 61000-4-4: 2004</b>
<b>EN 61000-4-5: 2006</b>	<b>EN 61000-4-6: 2009</b>
<b>EN 61000-4-11: 2004</b>	

This equipment is intended to be operated in all countries.

This declaration is made by  
ALLNET Computersysteme GmbH  
Maistraße 2  
82110 Germering Germany

Germering, 13.12.2013

  
\_\_\_\_\_  
Wolfgang Marcus Bauer  
CEO