

# ALL3073V3WLAN

## Network/WIFI socket 16A



# **Quick Install Guide**

### 1. Scope of delivery:

Please check packaging and content for damages:

- > Does something indicate transport damage to the packaging?
- Does the case show any traces of usage?

You must never put a damaged device into operation! In case of doubt, contact our technical support.

#### **Packaging content**

- ALLNET® ALL3073V3WLAN
- 1x network cable
- Quick install guide

### 2. Standard values:

IP address	192.168.0.100
ii uuuicss	152.100.0.100

#### **Reset to factory settings**

If your ALL3073V3WLAN is due to incorrect user settings or forgotten password not accessible anymore, you can reset the device to factory settings by performing the following instructions (all settings and values will be lost):

- Disconnect the device from power.
- Press RESET button with a prick out of non-conductive material and keep button pressed
- (The button needs to be kept pressed!)
- Connect ALL3073V3WLAN to power and wait about 45 seconds.
- Release RESET button.

Reset process is completed. All settings are reset to delivery status.

#### 3. Radio frequency & transmission power

Frequency	Frequency range	max. transmit power
2,4 GHz	2412 ~ 2472 MHz	100mW

### 4. Adapt ALL3073V3WLAN to your network

- a. Connect your ALL3073V3WLAN via the attached LAN cable to the network. Make sure you hear the connectors snap.
- b. ALL3073V3WLAN communicates with connected components via the TCP/IP protocol. The PC/MAC has to be located in the same network segment as the ALL3073V3WLAN, so the ALL3073V3WLAN can be recognized by the PC/MAC. The ALL3073V3WLAN has following IP address by default: 192.168.0.100 -

no user name, no password.

c. Now set the PC/MAC temporary to a free IP address between 192.168.0.1 and 192.168.0.254 (192.168.0.100 is already occupied by the ALL3073V3WLAN).

In perfect case you can set a second IP address for this sector with 192.168.0.xxx for your PC network interface.

d. By typing the address 192.168.0.100 into your web browser, the first page for language settings turns up:

ALL4175	× +								×
( 192.168.0.100			C	Q, Suchen	☆ 自 ♥	. ♦	ABP -	ø	≡
		NET <sup>®</sup>			01:00	2:18			
					AL	L4175			
				Choose your langu	lage				
		Choisissez votre language	Wählen Sie Ihre Sprache						
		选择你的语言		Seleziona la tua lingua					
		Seleccione el idioma deseado	Выберите Ваш язык	Choose your language					
			Deutsch - German 🔶						
			Save inputs						
			Copyright @ ALLNET GmbH Computersystem [Software: 3.30.1068]	le					

e. Choose the right language from the dropdown menu and save your

settings. The next configurations item appears automatically.

f. Now you can assign an IP address from your network segment to the ALL3073V3WLAN.

**Statically:** Here IP settings can be defined manually.

**DHCP:** ALL3073V3WLAN chooses an IP from your router automatically. Confirm the settings with "save entries".

S ALL4175	× +						0	x
<b>(</b> 192.168.0.100		C Q Suchen	5	1 🖻 🛡	+ 11	- <b>B</b>	ø	≡
	PALNET*			01:0	2:46			
		Netzwerk	Einstellung	Al	L4175			
	all4175 Hostiname							
	IP Angess Existent Unio							
		Manuelle Netzwerk	Einstellung					
	192.168.0.100 IP ADRESSE							
	255.255.255.0 Netmask							
	192.168.0.1 Default Gateway							
	192.168.0.1 ERSTER DNS							
	8.8.8.8 7. June 1918							
	Eingaben Speichen	n						
	Copyright & ALLNET Grabh Comp [Software: 3 30.1068]	utersysteme ]						

- g. The device adopts the settings. This process will take 10 seconds. When done, the page reloads with your defined IP address.
- h. Now, a page with time settings turns up, where you can define an own timeserver, use a listed server or set up the time manually.

< 🕘 🖻 http://19	192.168.3.1007 , D + C 🗞 ALL4175 🗙	
👍 🛃 Vorgeschlagene S	e Sites 🔻 🕘 System	
	ALLNET <sup>®</sup>	Achtung m und Uhrzeit sind nicht korrekt! zeichnungsfunktionen sind Deaktiviert!
	Hauntseite Funktionen Konfinuration	411 4175
	Europe  Berlin  Region STADT / ORT  Aktivet Deaktivient Zeitserver Aktivieren oder deaktimieren ptblime1.ptb.de NTP Server 1 ptblime2.ptb.de NTP Server 2 ntp0.fau.de NTP Server 3	
	pool.ntp.org NTP SERVERPOOL Zeit Anzeige (kann nur geandert werden wenn der Zeitserve D1:05:09 SYSTEM ZEIT D1:01.1970 SYSTEM DATUM Eingaben Speichern Copyright © 2011-2016 ALLINET Enteth Computersysteme	r (leaktivuori ist)
	[Software: 3.30.1068]	

i. Secure your settings with "save entries".

## 5. Checking for updates

When the IP configuration is done, an update to the latest software version is recommended. The update can be found in "configuration" -> "update settings". By clicking on "Checking for updates" you'll receive one of the following notifications:

a. No later versions found

or

b. Install update

and the second se	_			
http://192.168.3.100/	ည 🗝 🖒 📎 Warter	n auf 192.168.3.100 ×		6 🔝 😳
👍 🖉 Vorgeschlagene Sites 👻 🦉 System		,		
ALLNET			16;25:48	
Hauptseite Funktionen Konfigurat	tion		ALL4175	
Patch Da	ALL4175 0.02 3.30 Ite Prufung rde keine neuere Version gefunden! irmware ist Aktuell.	Update Prufung Installierte Patches/Updates	Version Isierung	

Perform the update check several times until you receive the notification from the picture above.

### 6. Create user

You should configure an Admin account, so that only you have access onto ALL3073V3WLAN's setups.

Choose "configuration" -> "web server and user"

Here you can create an Admin user and a normal user. The Admin user has full access to the web interface, the normal user may only see and operate the main page.

←) ⊕ http://192.168.3.100/ P ← C Warten auf 192.168.3.100 ×		- • • × •
🚖 🕘 Vorgeschlagene Sites 👻 🛃 System		
Hauptseite Funktionen Konfiguration Abmelden	16 : 32 : 52 ALL4175	
Hauptseite Funktionen Konfiguration Abmelden          Web server Einstellung       FTP Server einstellung       SSH Server einstellung         Imp://	ALL4175	
ADMIN KENNWORT Eingaben Speichern		
Copyright © 2011-2018 ALLNET GmbH Computersysteme [Software: 3.30 1088]		

## 7. Access-Point configuration

The ALL3073V3WLAN can also be configured as an own access point.

In "configuration" -> "Wi-Fi settings" the access point mode can be set up.

	2.168.3.100/	-	ר ל 💁 ALL4175	×			□ <u></u>
🙀 🛃 Vorgeschlagene S	iites 👻 🧃 System						
		NET <sup>®</sup>				10:38:12	
	Hauptseite Funk	tionen Konfiguration				ALL4175	
		Ausneschaltet Access Point	Wireless Client	W	ireless Einstellungen		
		WLAN MODE					
		ALL4175					
		6 •					
		KANAL					
		WPA2PSK-AES +					
		WEAN AUTH MODE			-		
		CHIFFRIERSCHLÜSSEL		PAS	SWORT ANZEIGEN		
			Eingaben Speichern				
			Copyright © 2011-2016 ALLNET GmbH C [Software: 3.30.1068]	omputersysteme			
	_						

**SSID:** Register any desired name for the network here. This name will be shown after scanning for networks.

**Channel:** Choose the transmitting channel here.

**Wi-Fi auth. mode:** Choose encryption mode here. WPA2PSK-AES is recommended.

**Cryptographic key:** Enter an arbitrary password here. The key is inquired by connecting to the ALL3073V3WLAN. Choose a secure password with at least 8 characters.

Secure your settings with "save entries".

The entries are confirmed. This process takes 120 seconds.

#### 7. Wireless-Client configuration

The ALL3073V3WLAN may also be connected to an existing Wi-Fi network.

In "configuration" -> "Wi-Fi settings" you can set up the Wi-Fi connection.

Choose "Wireless Client" to connect the device to an existing network. Click "search for access points" to find your Wi-Fi network.

LL41/5 × (+				
) 192.168.3.100	C <sup>e</sup> Q. Suchen	☆ 自 ♥ ♣ ⋒	- 🐵 -	9
		14:36:53		
Hauptseite Funktionen Konfiguration		ALL4175		
Ausgeschaltet Access Point WLAN MODE	Wireless Einstei	lungen		
Geben Sie hier die SSID des Access Po SSID	ein, mit dem sich das Gerät verbinden sol	_		
WPA2PSK-AES • WLAN AUTH MODE				
Passwort für die Anmeldung		FIGEN		
	ne Accesspoints Eingaben Speichern			
ce	ight © 2011-2016 ALLNET GmbH Computersysteme [Software: 3.30.1068]			

All surrounding networks will be displays. Select your network and confirm by clicking "choose".

S ALL4175	× +													x
<b>(</b> 192.168.3.100					C Q Suc	hen		☆ (		+	<b>î</b>	BP -	9	≡
												-		
		IET <sup>®</sup>							14:3	7:12				
	Hauptseite Funkti									L4175				
							Wireless Einstellur	igen						
		Ausgeschaltet	Access Point	Vireless Client										
		WLAN MODE												
		Geben Sie hier die S	SID des Access Poi	nt ein, mit dem <mark>s</mark> ich das Ge	rät verbinden sol									
		Gefundene Ad	ccesspoints											
		SSID		Sicherheit	Signal %	Mode								
		Mario WLAN T	fest	WPA2PSK-AES	86	11b/g/n	Wählen							
		ACPro		WPA2PSK-AES	39	11b/g/n	Wählen							
		ALLNET-INT2		WPA2PSK-AES	34	11b/g/n	Wählen							
		ABC001		WPA2PSK-AES	34	11b/g/n	Wählen	1						
				WPA2PSK-AES	29	11b/g/n	Wählen							
		ALLNET-Guest		WPA2PSK-AES	29	11b/g/n	Wählen							
		ALLNET-INT1		WPA2PSK-AES	29	11b/g/n	Wählen							
		alldis_technik		WPA2PSK-AES	29	11b/g/n	Wählen							
		ACPro		WPA2PSK-AES	15	11b/g/n	Wählen							
		·									J			
							Schliessen							
							Connessen							

"SSID" and "Wi-Fi auth. mode" will be filled automatically. You only need to type in the Wi-Fi key and confirm the settings with "save entries". The device takes all the settings within a duration of 120 seconds.

ALL4175	× +		_ 0 ×
( 192.168.3.100	v C Q, Suchen	合自 🛡 🖡 🏫 💩	• @ =
	Windows         Mario_wLAN_Test           SSD         WIAN_AUTH MODE           WIAN_AUTH MODE         CHEFFRERSCHLÜSSEL           SUCH Accesspoint         Eingaben Speichem	14:37:41 ALL4175	
	Copyright © 2011-2016 ALLNET GmbH Computersysteme [Software: 3.30.1060]		

The ALL3073V3WLAN can be reached at the registered IP address.

**IMPORTANT:** After 120 seconds, disconnect the LAN cable to avoid network conflicts.

**<u>NOTICE:</u>** The Wi-Fi you wish to connect shall not have any space character in its SSID. Otherwise a connection will not be established.

#### **Safety Instructions**

Please be sure to observe the following instructions:

#### **General notes**



- Only use the device for the purpose it was designed.
- Only use the device as described in the Quick Start Guide or manual.
- Any other use is considered improper and may result in property damage.
- Neither ALLNET<sup>®</sup> nor the dealer accepts liability for damage caused by improper or incorrect use.
- All safety instructions must be read through.
- The manual should be kept for future reference.

#### **Mounting instructions**

## (2) WARNING

- NEVER place the device near radiators, air conditioners or water sources. This greatly increases the risk of electric shocks, short circuits or fire.
- The humidity should be between 20% and 80%, otherwise condensation may occur.
- Protect the device from direct sunlight, extreme heat, open fire and dust. Otherwise, the risk of electric shocks, short circuits or fire increases.
- Never place the device on surfaces that are sensitive to heat.
- Do not use the device in damp rooms and under no circumstances in potentially explosive areas.
- The device is designed for use in enclosed spaces.

#### **Operating notes**



- Operate the device only with the voltage indicated on the device or on the included power supply unit.
- Any batteries present are only to be replaced with the same or an equivalent type.

- Do not use obviously defective devices. If the unit does not operate normally – especially if unusual odors or noises occur – unplug the power cord from the socket immediately.
- Never expose the device to direct sunlight during operation.
- Never operate the device near sources of heat.
- Protect the device from moisture, dust, liquids and vapors.
- Never open the device.
- Work on the device may only be carried out when the device has been disconnected from its power source.
- The device may only be operated by persons who have read the instructions or have been instructed in its operation by a competent person.

#### Instructions for repair and maintenance.

# RISK

- Repairs may only be carried out by trained, authorized personnel.
- Regular maintenance is not necessary.
- Never open the device.
- For cleaning work, disconnect the device from its power source.
- Do not use any cleaning agents containing solvents for cleaning, but only a soft, dry antistatic cloth.
- It is forbidden to make any modifications to the unit.
- Damaged devices or damaged components may no longer be used.



ALLNET GmbH Computersysteme declares that the device **ALL3073v3WLAN** is in compliance with the essential requirements and other relevant provisions of Directive 2014/30/EU. The Declaration of conformity can be found under this link: <u>http://ce.allnet.de</u>

ALLNET GmbH Computersysteme Maistrasse 2 82110 Germering

Tel.: +49 (0)89 894 222 - 22 Fax: +49 (0)89 894 222 - 33 Email: <u>info@allnet.de</u>



CE Marking is the symbol as shown above. The letters "CE" are the abbreviation of the French phrase "Conformity European" which literally means "European Conformity". The terms initial use was as the "EC Mark". With the Directive 93/68/EEC from 1993 it was officially replaced by the "CE Marking". Nowadays the "CE Marking" is used in all EU official documents.





This symbol on the product or on its packaging indicate that this product is not to be disposed with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of electrical waste or electronic equipment. The separate collection and recycling of your waste equipment will help to conserve natural resources and ensure that it is recycled in a manner that protects

DE13101093 human health and environment. For more information about where you can dispose your waste equipment, please contact your local city office, your household disposal service or the shop where you purchased the product.



This recycle logo indicates that this product can be recycled, not that the product has been recycled. It is possible that this device will not be accepted in all recycling collection systems.



The recycling codes are used to guarantee the correct handling of waste. It is an internationally recognized classification that assigns a unique number to each waste material. This number provides information on how the waste material can best be recycled to ensure the least possible impact on the

environment. The code PAP 22 describes these instructions for the device, which were printed on paper. They should be disposed of through the usual recycling channels, such as waste paper collection points.

The RoHS directive aims to restrict certain dangerous substances commonly used in electronic and electronic equipment. This RoHS compliant symbol indicate the component is tested for the presence of Lead (Pb), Cadmium (Cd), Mercury (Hg), Hexavalent chromium (Hex-Cr), Polybrominated biphenyls (PBB), and Polybrominated diphenyl ethers (PBDE). For Cadmium and Hexavalent chromium, there must be less than 0.01% of the substance by weight at raw homogeneous materials level. For Lead, PBB, and PBDE, there must be no more than 0.1% of the material, when calculated by weight at raw homogeneous materials. Any RoHS compliant component must not have more than 100 ppm of mercury and the mercury must not have been intentionally added to the component.